

•

•

•

4119 White Bear Parkway, St. Paul, MN 55110 USA

- Phone (651) 429-1100, Fax (651) 429-1122
- Toll Free (800) 4-CORTEC, E-mail info@cortecvci.com

Internet http://www.cortecvci.com

## Comparing the Corrosion Protection of Cutting Fluids

Purpose:	To compare the corrosion inhibiting abilities of VpCI-345 to the Metal Seal product.		
Method:	ASTM D-1748 Humidity Cabinet		
Materials:	3 Keyways KO Manufacturing 'Metal Seal' VpCI-345 Lab Grade Methanol VpCI-416		
Procedure:	redure: The following procedure was used:		
Results:	<ol> <li>The 3 keyways were cleaned prior to testing.         <ul> <li>a. Two of the keyways were cleaned using methanol.</li> <li>b. The third keyway was cleaned in a 5% solution of VpCI-416.</li> </ul> </li> <li>After cleaning, each part was allowed to air dry.</li> <li>After drying, the parts were prepared as follows:         <ul> <li>a. The first part was left untreated, to be tested as a control.</li> <li>b. The second part was dipped in Metal Seal, which was used as received (4.5%, according to the customer).</li> <li>c. The third part was dipped in a 5% solution of VpCI-345.</li> </ul> </li> <li>After dipping, all parts were allowed to air dry.</li> <li>Parts were then placed in ASTM D-1748 humidity cabinet.</li> <li>Parts were visually inspected periodically.</li> <li>After 312 hours, all parts were removed from ASTM D-1748 humidity cabinet.</li> <li>All parts were visually inspected and photographed.</li> </ol>		
	Protection	Time to Failure (Hours)	]
	None (Control)	<6	
	'Metal Seal'	<8	
	VpCI-345 (5%)	312	]
Conclusion:	Humidity testing provided drastic	corrosion protection results. The	e keyway dipped in

Humidity testing provided drastic corrosion protection results. The keyway dipped in the Metal Seal fluid started to corrode within 8 hours, and it was almost completely covered in corrosion after 312 hours of testing. VpCI-345 did not corrode at all for the first 300+ hours of testing. These results are to be expected considering the Metal Seal product uses an old VCI chemistry, while VpCI-345 uses a combination of newer, more effective inhibitors.



**Project #:** 08-219-1825(bis)



Figure 1: Three keyways after 312 hours in ASTM D-1748 Humidity cabinet testing. From left to right: control, Metal Seal, VpCI-345.